

# Aufheizvorschrift A 0 / Initial-heating-up instruction A 0 Für alle monolithischen Refratechnik Produkte / For all monolithic Refratechnik products

**Nur gültig für die Aufheizung und Abkühlung bereits aufgeheizter Zustellungen.**

Beispiel für Ofenanlagen mit einer Betriebstemperatur von 1350 °C.  
**Beim Aufheizen die maximale Anwendungstemperatur nicht überschreiten!**

Diese Aufheizvorschrift ist eine allgemeine Richtlinie für das Wiederaufheizen der betreffenden Produkte unter Idealbedingungen. Eine Anpassung an die Gegebenheiten am Ort der Zustellung ist daher immer erforderlich. Beachten Sie bitte unbedingt unsere „Hinweise zur Aufheizung monolithischer Feuerfestprodukte“.

**Only valid for the heating-up and cooling down of linings that have already undergone the initial heating-up procedure!**

Example for large furnaces with an operation temperature of 1350 °C.  
**Do not exceed the maximum service temperature when heating up!**

This heating-up instruction is a general guideline for the heating-up again procedure of the respective products under ideal conditions. The actual conditions may vary so that the heating up-curve always has to be adjusted. Please take notice of our "remarks on the heating-up of monolithic refractories".

