

Processing instructions V 15.0

REFRAPROTECT CA and CM

Note: Please read the product information sheet first, to ensure that these are the right processing instructions for your product. This document describes the application procedure for the surface sealant / protective coating materials **REFRAPROTECT CA** and **CM**, which are used to protect refractory products containing carbon and/or SiC. The **REFRAPROTECT CA** product group is used with alumina-based products (e.g. compounds for blast furnace runners). The **REFRAPROTECT CM** product group is used with MgO-based products (e.g. MgO-C bricks).

The instructions contained in this document must be complied with during processing and installation of the respective product. Modification of or deviations from the processing instructions can lead to major problems during installation, and possibly to total failure of the installed refractory material.

These instructions provide general guidelines for storage, processing, and installation of the specific refractory material. If, due to specific site conditions, it appears necessary to deviate from the procedures described here, please consult Refratechnik Steel GmbH before starting work.

Storage

- In general: Store under cool, dry, and frost-free conditions.
- The shelf life stated in the product information sheet is valid from the production date, and only if storage is in accordance with our recommendations. The production date is stated on the packaging label.
- Under certain circumstances, material that has been properly stored may still be usable even after expiry of the stated shelf life. In such a case, conduct a setting test with a sample before using the material. In case of doubt, the stored material can be checked by Refratechnik Steel GmbH.
- Incorrect storage can greatly reduce shelf life, and can impair product quality.
- The original pallet wrapping foil should be left intact for as long as possible to

protect the product. However, the foil is not a substitute for storage under cover.

- Also standing water, e.g. due to inadequate drainage of the storage area, can damage the material.
- Stacking of the goods supplied by us (in sacks, Big Bags, etc.) is done under the sole responsibility of the shipping company or customer. Refratechnik Steel GmbH accepts no liability for possible consequential damage (damaged packaging, personal injury, etc.).

Health and safety

- Always wear suitable safety goggles, dust mask, protective clothing, and working gloves.
- Always wash thoroughly after working with the material.
- Observe the information in the safety data sheet.

General information

- These products provide a protective coating for refractory materials containing carbon and/or SiC. **REFRAPROTECT CA** and **CM** seal the monolithic surface, thereby protecting the components from oxidation and decarbonization without disturbing the drying process. Depending on operating conditions, **REFRAPROTECT CA** or **CM** can also serve as a protective coating against external influences.
- **REFRAPROTECT CA** and **CM** are delivered dry in 25-kg sacks, and must be mixed with water on site before use.
- Always mix complete packaging units (1 sack). The use of partial quantities can lead to demixing and changed material properties.
- Only use clean drinking water, as otherwise the setting behaviour may be affected.

- **REFRAPROTECT CA** and **CM** are processed at room temperature (5...25 °C).
- Low temperatures can retard or even stop the setting process. Therefore, the temperature of material and mixing water must be at least 5 °C. It might be necessary to heat the installation site.
- On the other hand, the setting process may be significantly accelerated at temperatures above 25 °C.
- Before using the material on a large surface for the first time, we recommend carrying out an individual test on a representative component, and subject it to the normal operating conditions to determine whether **REFRAPROTECT CA** or **CM** is suitable for the intended purpose.
- Please take the expansion of the refractory material for your specific furnace application into account. The reversible and irreversible expansion values and the respective material properties are given in the product information sheet. Depending on the furnace operating conditions and the specific characteristics of the refractory material, any arising stresses and pressures must be compensated by suitably designed expansion joints.
- During installation of the monolithic refractory material, please ensure correct anchoring to the existing furnace structure and/or to the existing or adjacent refractory material (e.g. with steel anchors, ceramic anchoring systems, etc.).
- Suitable measures must be taken to ensure that the water or water vapour generated during the drying & heating up process is removed from the refractory lining without pressure build-up.
- With certain furnace structures and refractory linings, the drying process can cause water or water vapour to diffuse outwards in the direction of the furnace shell instead of inwards to the hot side (furnace chamber). Therefore, suitable measures must be taken to ensure that the water or water vapour can escape to atmosphere. For this purpose, 10-mm holes drilled into the outer furnace surface (at least 5 per m²) have proved to be successful.
- In order to ensure a continuous drying process, the entire furnace chamber must always be flushed with an adequate amount of fresh air during the entire drying and heating up procedure. The air circulating in the furnace chamber may never be saturated with moisture.

Mixing

- Mixer, tools, conveying equipment, etc. must be clean and free from any form of contamination.
- One packaging unit of dry material is mixed in a suitable container with the corresponding amount of drinking water (see product information sheet). A drilling machine fitted with an agitator is recommended for mixing.
- The required amount of drinking water is filled into a suitable mixing container. Slowly pour the dry material into the container while the agitator is running (pouring time: 1...2 minutes). Then continue agitating for 3 minutes. Next, allow the mixture to rest for about 5 minutes, then continue mixing for 1 more minute. After preparing the **REFRAPROTECT CA** or **CM** mixture in this way, it is ready for processing.

- To prevent contamination of the mixed **REFRAPROTECT CA** or **CM**, we recommend sealing the mixing container with a tight cover.
- Under normal storage conditions, and if kept in a tightly sealed container, the prepared mixture remains processable for up to 2 days. We recommend that the mixture is agitated briefly (2 minutes) before processing.

Processing

- **REFRAPROTECT CA** and **CM** are applied with the help of spatulas, trowels, rollers, etc., immediately after removing the formwork from the refractory surface that is to be covered with **REFRAPROTECT CA** or **CM**.
- The thickness of the applied layer should be as thin as possible, and not exceed 3,0 mm. The mixture should be applied as evenly as possible, and in a single coat.

Setting and curing

- **REFRAPROTECT CA** and **CM** is cured after about 1 hour at room temperature, after which a protective layer is already formed on the monolithic refractory component.

Drying and heating up

- Drying can start 1 hour after the protective layer has been applied.
- There is no specific drying or heating up procedure for **REFRAPROTECT CA** or **CM**. Regarding the drying and heating up procedures of the respective base material, the corresponding data sheets must be observed.