REFRATECHNIK

Refratechnik Steel GmbH Am Seestern 5 40547 Düsseldorf Germany Phone: +49 211 5858 0 Fax: +49 211 5858 49 steel@refra.com www.refra.com

# Processing instructions V 1.71 **REFRACAST® Nanobond MW, LW**

Note: Please read the product information sheet first, to ensure that these are the right processing instructions for your product. This document describes the application procedure for cement-free, lightweight **REFRACAST® Nanobond MW, LW** refractory concretes. It does not apply for **REFRACAST®** concrete types **MW** and **LW**.

The instructions contained in this document must be complied with during processing and installation of the respective refractory concrete. Modification of or deviations from the processing instructions can lead to major problems during installation, and possibly to total failure of the installed refractory material. These instructions provide general guidelines for storage, processing, and installation of the specific refractory material. If, due to specific site conditions, it appears necessary to deviate from the procedures described here, please consult Refratechnik Steel GmbH before starting work.

## Storage

- In general: Store under cool, dry, and frost-free conditions.
- The liquid binding agent must always be stored at a temperature of > -20 °C.
- The shelf life stated in the product information sheet is valid from the production date, and only if storage is in accordance with our recommendations.
   The production date is stated on the packaging label.
- Under certain circumstances, material
  that has been properly stored may still
  be usable even after expiry of the stated
  shelf life. In such a case, conduct a setting test with a sample before using the
  material. In case of doubt, the expired
  material can be checked by Refratechnik
  Steel GmbH.
- Incorrect storage can greatly reduce shelf life, and can impair product quality.
- The original pallet wrapping foil should be left intact for as long as possible to

- protect the product. However, the foil is not a substitute for storage under cover.
- Also standing water, e.g. due to inadequate drainage of the storage area, can damage the material.
- Stacking of the goods supplied by us (in sacks, Big Bags, etc.) is done under the sole responsibility of the shipping company or customer. Refratechnik Steel GmbH accepts no liability for possible consequential damage (damaged packaging, personal injury, etc.).

### **Health and safety**

- Always wear suitable safety goggles, dust mask, protective clothing, and working gloves.
- Always wash thoroughly after working with the material.
- Observe the safety data sheets of the dry mixture and the liquid binding agent.

## **General information**

- This product is an inorganic-chemically setting lightweight refractory concrete.
   Delivered dry in 25 kg sacks or in Big Bags, it is mixed with the supplied liquid binder on site, and then cast. Curing occurs at room temperature.
  - REFRACAST® Nanobond concretes are always supplied as two-component materials (dry mixture + liquid binding agent).
- Always mix complete packaging units (1 sack / 1 Big Bag). The use of partial quantities can lead to demixing and changed material properties.
- The dry mixture is then mixed exclusively with the liquid binding agent supplied – never add water.
- Low temperatures can retard or even stop the setting process. Therefore, the temperature of material and liquid binding agent must be at least 5 °C. It might be necessary to heat the installation site.

# **REFRATECHNIK**

- On the other hand, the setting process may be significantly accelerated at temperatures above 25 °C.
- Please take the expansion of the refractory material for your specific furnace application into account. The reversible and irreversible expansion values and the respective material properties are given in the product information sheet. Depending on the furnace operating conditions and the specific characteristics of the refractory material, any arising stresses and pressures must be compensated by suitably designed expansion joints.
- During installation of the monolithic refractory material, please ensure correct anchoring to the existing furnace structure and/or to the existing or adjacent refractory material (e.g. with steel anchors, ceramic anchoring systems, etc.).
- Suitable measures must be taken to ensure that the water or water vapour generated during the drying & heat-up process is removed from the refractory lining without pressure build-up.
- With certain kiln structures and refractory linings, the drying process can cause the generated water or water vapour to diffuse outwards in the direction of the furnace shell instead of inwards to the hot side (kiln chamber). Therefore, suitable measures must be taken to ensure that the water or water vapour can escape to atmosphere. For this purpose, 10-mm holes drilled into the kiln's outer steel shell (at least 5 per m²) have proved to be successful.
- Regarding the build-up of water vapour pressure, attention must be given to the entire wall structure of the lining (wear lining/permanent lining/insulation). In the area behind the wear lining, it must also be ensured that only such materials are used, which provide an adequate (highest possible) permeability to the steel shell.

- If the permanent lining/insulating layers are used several times and only the wear lining is replaced, they can become clogged in the course of time due to moisture transport with dust contaminations, salts, etc., thereby also impeding moisture transport. Consequently, multiple use of such layers must be seen as counterproductive in terms of dewatering performance. It might even be safer also to replace the permanent lining, in order to ensure perfect flowthrough to the cold side.
- To ensure a continuous drying process, the complete kiln chamber must always be flushed with an adequate amount of fresh air during the entire drying and heat-up procedure. The air circulating in the kiln chamber may never be saturated with moisture.
- During heat-up, it essential that flames do not impinge on the refractory lining only in small areas. Local overheating can result is severe damage of the refractory material. Therefore, it must be ensured that the entire lining surface is heated uniformly and without significant temperature differences.

## Mixing

- Mixer, tools, conveying equipment, etc. must be clean and free from any form of contamination.
- We recommend the use of a positive mixer, but this is not essential.
- Mix only as much material at a time, as can be processed within about 20 minutes.
- Data on the maximum and minimum amounts of liquid binding agent to be added is given in the product information sheet or on the packaging label. Please note that the quantities to be added are stated in I/100 kg or kg/ 100 kg.

- If in doubt about the reactivity of the liquid binding agent (e.g. if its shelf life has expired or undefined storage conditions, etc.), please contact the R&D Dept. of Refratechnik Steel GmbH before starting work.
- First, briefly mix the dry material for about 30 seconds to restore the consistency after any demixing that might have occurred during transport.
- Next, add the minimum amount of liquid binding agent while continuing to mix the material. Continue mixing for about 2 minutes until a thorough mix is obtained.
- Frequently, the required consistency is obtained only at the end of the mixing period, because the fine portions in the product must be broken down first. Therefore, you should wait until the full mixing time has elapsed, and don't try to obtain the required consistency in a shorter time by adding more liquid binding agent. The material's consistency can change quite abruptly from "too dry" to "exactly right". If necessary, the remaining amount of liquid binding agent can be added until the required consistency is obtained. Hereby, the maximum amount of liquid binding agent may not be exceeded.
- Then continue mixing for about 1 more minute
- Do not mix longer than the recommended mixing time, as otherwise the lightweight additives can suffer mechanical damage.

## **Processing**

- If using formwork, make sure it is sufficiently stable, and that its surfaces are smooth. Use formwork release oil.
- During casting, no moisture may be drawn out of the cast material by adjacent dry and absorbent surfaces. Therefore, any existing refractory lining should be pre-wetted. Any moisture-

sensitive materials, such as insulation, should be covered with foil.

- While casting the material, or shortly afterwards, the concrete must be compacted by rodding or vibration (e.g. with an internal vibrator).
- Because with lightweight refractory concretes, high thermal insulation is more important than high strength, internal vibrators must only be used for a short time to prevent mechanical damage to the lightweight additives. To prevent air inclusions, withdraw the vibrator slowly from the concrete.

#### Setting and curing

- As opposed to cement-bonded refractory concretes, Nanobond-bonded concretes generate a negligible amount of heat during curing. Cooling of the concrete surface by spraying it with water, as generally done with cement-bonded concretes, is not required for Nanobond concrete.
- Generally, it takes between 6 and 12
  hours before the concrete has cured sufficiently to permit removal of the formwork. Ambient temperatures in midsummer may considerably shorten this time, while winter temperatures or the use of material stored in cold places may lengthen it.
- removed after the material has fully cured.

  <u>Caution</u>: In some cases, the lining core may not yet be solidified, even though the outer face of the casting is fully set. If in doubt, always allow the full recom-

mended curing time of 24 hours.

Of course, the formwork may only be

 In a direct comparison, the strength of Nanobond concrete after setting (24 hours) is lower than that of hydraulically bonded concretes. However, its strength increases significantly after drying, and above a temperature of about 800 °C it is equal to that of liquefied, hydraulically bonded refractory concrete.

- Full setting of the refractory concrete requires at least 24 hours. During that time, the concrete must be protected from frost.
- The liquid binding agent must always be stored at a temperature of > -20 °C.
   During processing, the temperature of the mixed concrete and liquid binder must be kept at > 5 °C.

## Drying and heating up

- Compared with hydraulically bonded refractory concretes, Nanobond-bonded concretes are significantly less sensitive during heat-up. Drying / heating up can be started immediately after removal of the formwork.
- Refractory linings should be dried or heated up immediately after installation in order to expel the contained water.
   Freshly installed refractory linings should not be left undried for longer periods. In exceptional cases, please contact Refratechnik Steel GmbH beforehand.
- Please check the product information sheet to ensure that you have the right heat-up instructions for your product.
- During the first heat-up, also make sure that no other materials are heated up, which are not suited for fast heating up.
- The heat-up instructions must always be followed precisely. Hereby, it must be ensured that the respective heating curve is followed, monitored, and recorded by means of several correctlypositioned thermocouples. Moreover, a homogeneous temperature distribution

must be ensured throughout the refractory lining.

3