Refratechnik Ceramics GmbH Barkhausener Str. 55 49328 Melle Germany Phone: +49 5427 810 Fax: +49 5427 81 102

ceramics@refra.com

REFRATECHNIK

Processing instructions REFRATHERM® G

The specifications listed in this document are to be observed when processing and installing the respective insulating concrete! Modification of or deviation from the processing specifications can lead to considerable installation problems and possibly to a complete failure of the installed refractory material! This processing specification describes general guidelines for the storage, processing and installation of the refractory material specified. If, e.g. due to individual construction site conditions, it seems necessary to deviate from the procedure described here, be sure to consult Refratechnik Ceramics GmbH before processing!

General:

• REFRATHERM G is a granular insulating infill based on lightweight fireclay, which can only be used as backup insulation. Delivered dry in bags, without any further additives. Volume change during storage and transport has no effect on the quality.

- In general: store in a dry place!
- The material is not subjected to an expiration date.
- The original shrink wrap foil should be left around the pallets for as long as

- possible for additional protection. The pallet protection foil does not replace a storage under cover.
- Standing wetness, e.g. through insufficient drainage of the storage space can also damage the material.
- . Stacking of the goods delivered by us (bagged goods, big bags, etc.), is at the liability of the forwarder or customer. Refratechnik Ceramics GmbH bears no responsibility for any resulting consequential damages (damage to the packaging, personal injury, etc.).

Health and safety:

- · Always use suitable eye protection, dust mask, protective clothing and work gloves!
- Observe the safety data sheet!

Processing:

- Store material in a dry place until use!
- Distribute the material in the application area and compress it a little by poking.